


Current Channel Information

Push the TV button, and the current channel number and station name will be displayed for approximately 10 seconds.



Picture Quality Adjustment

The screen colour hue, colour density, and brightness can be adjusted.

1. Push the picture/sound quality button, and then push the **画質** control assist button.



2. Push the appropriate control assist button to adjust.

色合い Hue

- ◀ Increase reds
- ▶ Increase greens

色濃さ Density

- ◀ Lighten colour
- ▶ Deepen colour

明るさ Brightness

- ◀ Brighten
- ▶ Darken



Advice:

The screen will return to the previous display after about 10 seconds after finishing operation.