

Storing Stations

- Manual Preset Storage

Up to 5 stations for both AM and FM broadcasts can be stored.

1. Push the tuning button to start receiving the station you wish to store.
2. Select 1 control assist button you wish to store on and push until a beep is heard.
Audio will be temporarily cut, and once audible again, storage is complete.
The stored station and frequency will be shown in the display area.
3. From now on, when a control assist button is pushed the station stored on that button will be received.



Advice:

- Each control assist button can store 2 stations, 1 for AM broadcasts, and 1 for FM broadcasts.
- If battery terminals are removed, memory will be cleared.
- When outside the reception area for the stored station, when the memory button is operated, the station name may be different.