


Relay Reception

When you wish to continue listening to the same broadcast on a long-distance drive, if relay reception is turned ON, then if when separated from the broadcast station service area, the unit will continue receiving the same broadcast from an affiliated station.

1. Push the picture/sound quality button, and then the **TV設定** (TV Settings) control assist button.



2. Push the **次ページ** control assist button.



3. Push the **リレー** control assist button. Each time this is pushed, relay reception will switch on/off. When receiving a relay broadcast, the control assist button display colour will change.



Advice:

Relay reception is only possible when in TV mode. The button will not be displayed in video mode.