

Track Cuing


It is possible to advance or reverse up to 7 tracks from the track being played currently, and cue the desired track.

To listen to a track after the current track

1. Push the Δ part of the track selection button or control assist button the appropriate number of times for the number of tracks you wish to skip. The specified number of tracks will be displayed on the screen.
2. The tape will advance to the start of the track and begin playback.

Example:

When desired track is 3 tracks after the current.



Push one of these buttons 3 times