

Displaying MD Track Title

1. Push the **設定** control assist button.
(Only if MD changer is installed)



2. Push the **表示切換** control assist button twice.



3. The track title will be displayed.



Advice:

- Each time the **表示切換** (change display) control assist button is pushed, the display will change through the following modes:
Disc Title → Track Title → Playing Time Display
- When an MD with no title data is inserted, NO TITLE will be displayed in the graphic display area.
- When the title is more than 24 characters (12 for full width characters), by using the **送り** control assist button, the title can be advanced to display the rest of the characters.
If within this number, the **送り** button will not be displayed.
- Some title characters can not be displayed by this system.