

Dolby* NR Button

Use this function when playing a tape recorded in Dolby NR.

1. Push the **設定** control assist button.



2. Push the **□□** control assist button
When this button is pushed, the indicator will be displayed onscreen.
Push again to cancel.
3. Push the **戻る** control assist button to return to step 1.



* Dolby and the Double D mark **□□** are registered trademarks of Dolby Laboratories Licensing Corporation and Dolby Noise Reduction is manufactured under license from Dolby Laboratories Licensing Corporation.