

Advice:

- The buzzer that sounds when reversing, indicates that the selector lever is in the R position, and is not a warning buzzer to indicate a hazard.
- When the rear view screen is displayed, if an MMCS control panel button is pushed, such as the current location button, the screen will change from the rear view screen to the screen of the selected button.
- In the following situations, the screen may be difficult to see, but this is not a fault.
 - In a dark place (at night)
 - When sunlight or the light from headlights is focused directly on the camera lens.
- If the camera lens is dirty, hazards will not be sufficiently visible. If there is water droplets, snow, mud etc., on the lens, wipe off carefully.