

To listen to a track before the current track


1. Push the V part of the track selection button or control assist button the appropriate number of times for the number of tracks you wish to skip. In this case the current track will be included. The specified number of tracks will be displayed on the screen.
2. The tape will reverse to the start of the track and begin playback.

Advice:

- When the silent gap between tracks is within 4 seconds, or there is loud noise recorded between tracks, the tape may not be stopped at the beginning of the song.
- If there is a long break in the recorded sound, or it is very soft or at a low level for a long time, the tape may be stopped at that point.

Example:

When desired track is 3 tracks before the current.



Push one of these buttons 4 times