


## Changing the broadcast station

### Using the 文字情報 button

1. When viewing the FM multi broadcast, the receivable FM multi broadcast stations will be displayed when 文字情報 is pushed.
2. Push the control assist button of the desired FM multi broadcast station to display the program menu of the selected FM multi broadcast station.



### Using the control assist button

When viewing an FM multi broadcast, push the 他局 (Other Station) control assist button to display the receivable stations.

#### Advice:

- When other FM multi broadcast stations can not be received, the screen will return to its previous state before 他局 (Other Station) was pushed.

